

Instruction 51-1017
4-23-06

Copyright© 2002, 2004, 2006
by S&S Cycle, Inc.
All rights reserved.
Printed in the U.S.A.

S&S® Cycle, Inc.
14025 County Highway G, PO Box 215
Viola, Wisconsin 54664
Phone: 608-627-1497 • Fax: 608-627-1488
Technical Service Phone: 608-627-TECH (8324)
Technical Service Email: sstech@sscycle.com
Website: www.sscycle.com



Instruction 51-1017
4-23-06

Copyright© 2002, 2004, 2006
by S&S Cycle, Inc.
All rights reserved.
Printed in the U.S.A.

S&S® Cycle, Inc.
14025 County Highway G, PO Box 215
Viola, Wisconsin 54664
Phone: 608-627-1497 • Fax: 608-627-1488
Technical Service Phone: 608-627-TECH (8324)
Technical Service Email: sstech@sscycle.com
Website: www.sscycle.com



Installation Instructions: Copper Head Gaskets

In some instances, S&S® provides copper head gaskets in place of fiber-type gaskets. The following assembly procedures must be followed for leak-free operation.

1. Inspect cylinder and cylinder head gasket surfaces for damage or irregularities which may prevent gasket from sealing. Pulling-out of threaded insert for cylinder head bolts is potential problem with older, worn shovelheads.
2. Clean gasket surfaces of cylinder and head with residue-free solvent such as lacquer thinner.

WARNING

Many solvents are highly flammable and the fumes toxic if inhaled. Insure adequate ventilation during use, avoid sparks or open flame, and observe solvent manufacturer's precautions and instructions.

3. These bare copper gaskets require sealant for leak free operation. Coat both sides of head gasket and coat head gasket surfaces on both the cylinder and the head with Gasgacinch®. Allow time to dry before assembly.

NOTE - Several years ago S&S supplied copper head gaskets with printed silicone beads around the oil passages. Gasgacinch® should not applied to these gaskets.

4. Install cylinder heads according to standard procedure and torque head bolts according to application. Lubricate bolt threads and underside of bolt head with a light coat of engine oil prior to installation.

Installation Instructions: Copper Head Gaskets

In some instances, S&S® provides copper head gaskets in place of fiber-type gaskets. The following assembly procedures must be followed for leak-free operation.

1. Inspect cylinder and cylinder head gasket surfaces for damage or irregularities which may prevent gasket from sealing. Pulling-out of threaded insert for cylinder head bolts is potential problem with older, worn shovelheads.
2. Clean gasket surfaces of cylinder and head with residue-free solvent such as lacquer thinner.

WARNING

Many solvents are highly flammable and the fumes toxic if inhaled. Insure adequate ventilation during use, avoid sparks or open flame, and observe solvent manufacturer's precautions and instructions.

3. These bare copper gaskets require sealant for leak free operation. Coat both sides of head gasket and coat head gasket surfaces on both the cylinder and the head with Gasgacinch®. Allow time to dry before assembly.

NOTE - Several years ago S&S supplied copper head gaskets with printed silicone beads around the oil passages. Gasgacinch® should not applied to these gaskets.

4. Install cylinder heads according to standard procedure and torque head bolts according to application. Lubricate bolt threads and underside of bolt head with a light coat of engine oil prior to installation.