



Because every industry has a leader

Copyright © 2007
by S&S[®] Cycle, Inc.

All rights reserved.
Printed in the U.S.A.

Secondary Drive Belt Handling and Installation

DISCLAIMER:

S&S parts are designed for high performance, off road, racing applications and are intended for the very experienced rider only. The installation of S&S parts may void or adversely effect your factory warranty. In addition such installation and use may violate certain federal, state, and local laws, rules and ordinances as well as other laws when used on motor vehicles used on public highways, especially in states where pollution laws may apply. Always check federal, state, and local laws before modifying your motorcycle. It is the sole and exclusive responsibility of the user to determine the suitability of the product for his or her use, and the user shall assume all legal, personal injury risk and liability and all other obligations, duties, and risks associated therewith.

SAFE INSTALLATION AND OPERATION RULES:

Before installing your new S&S part it is your responsibility to read and follow the installation and maintenance procedures in these instructions and follow the basic rules below for your personal safety.

- Gasoline is extremely flammable and explosive under certain conditions and toxic when breathed. Do not smoke. Perform installation in a well ventilated area away from open flames or sparks.
- If motorcycle has been running, wait until engine and exhaust pipes have cooled down to avoid getting burned before performing any installation steps.
- Before performing any installation steps disconnect battery to eliminate potential sparks and inadvertent engagement of starter while working on electrical components.
- Read instructions thoroughly and carefully so all procedures are completely understood before performing any installation steps. Contact S&S with any questions you may have if any steps are unclear or any abnormalities occur during installation or operation of motorcycle with a S&S part on it.
- Consult an appropriate service manual for your motorcycle for correct disassembly and reassembly procedures for any parts that need to be removed to facilitate installation.
- Use good judgement when performing installation and operating motorcycle. Good judgement begins with a clear head. Don't let alcohol, drugs or fatigue impair your judgement. Start installation when you are fresh.
- Be sure all federal, state and local laws are obeyed with the installation.
- For optimum performance and safety and to minimize potential damage to carb or other components, use all mounting hardware that is provided and follow all installation instructions.
- Motorcycle exhaust fumes are toxic, poisonous and must not be breathed. Run motorcycle in a well ventilated area where fumes can dissipate.


IMPORTANT NOTICE:

Statements in this instruction sheet preceded by the following words are of special significance.



WARNING

Means there is the possibility of injury to yourself or others.



CAUTION

Means there is the possibility of damage to the part or motorcycle.

NOTE

Other information of particular importance has been placed in italic type.

S&S recommends you take special notice of these items.

WARRANTY:

All S&S parts are guaranteed to the original purchaser to be free of manufacturing defects in materials and workmanship for a period of twelve (12) months from the date of purchase. Merchandise that fails to conform to these conditions will be repaired or replaced at S&S's option if the parts are returned to us by the purchaser within the 12 month warranty period or within 10 days thereafter.

In the event warranty service is required, the original purchaser must call or write S&S immediately with the problem. Some problems can be rectified by a telephone call and need no further course of action.

A part that is suspect of being defective must not be replaced by a Dealer without prior authorization from S&S. If it is deemed necessary for S&S to make an evaluation to determine whether the part was defective, a return authorization number must be obtained from S&S. The parts must be packaged properly so as to not cause further damage and be returned prepaid to S&S with a copy of the original invoice of purchase and a detailed letter outlining the nature of the problem, how the part was used and the circumstances at the time of failure. If after an evaluation has been made by S&S and the part was found to be defective, repair, replacement or refund will be granted.


ADDITIONAL WARRANTY PROVISIONS:

- (1) S&S shall have no obligation in the event an S&S part is modified by any other person or organization.
- (2) S&S shall have no obligation if an S&S part becomes defective in whole or in part as a result of improper installation, improper maintenance, improper use, abnormal operation, or any other misuse or mistreatment of the S&S part.
- (3) S&S shall not be liable for any consequential or incidental damages resulting from the failure of an S&S part, the breach of any warranties, the failure to deliver, delay in delivery, delivery in non-conforming condition, or for any other breach of contract or duty between S&S and a customer.
- (4) S&S parts are designed exclusively for use in American v-twin motorcycles. S&S shall have no warranty or liability obligation if an S&S part is used in any other application.

CAUTION

Proper Belt Handling: Improper belt handling before and during belt installation can dramatically shorten the life of a secondary drive belt. To avoid causing damage to the belt, follow the guidelines below:

DO NOT CRIMP THE BELT




Belt crimping occurs when the belt is flexed so far that it takes a permanent “set”. Once this happens the tensile cords are damaged. This will result in premature failure.

To avoid this, follow these guidelines while handling the belt:

NOTE: After the belt is properly installed, the belt can be used on sprockets smaller than five inches in diameter.

- Do not forward bend a drive belt (bending the belt so that the teeth move towards each other) tighter than a five inch diameter.
- Do not back bend a belt (bending the belt so that the teeth move away from each other) tighter than a ten inch diameter.



DO NOT TWIST THE BELT



- This includes coiling the belt, so that it takes up less space.

DO NOT USE TOOLS TO PRY THE BELT INTO POSITION

Belt Installation Procedure

1. Remove old belt by following the instructions in your factory service manual.
2. Inspect the belt drive components for excessive wear or damage.
3. Install new belt according to factory service manual.

Belt Adjustment

1. Adjust belt to the specifications called out in the factory service manual.

NOTE: For high performance situations, less belt deflection (within the specified range) will yield the best belt performance.

Belt Maintenance

1. Periodically check belt for damage.
2. Oil, grease, dirt and other contaminants should be regularly cleaned off of the belt with a light cleaner.